



HRPD Sample Changer – Serial Protocol Manual

DRAFT

HRPD Sample Changer – Serial Protocol

Contents

HRPD Sample Changer Serial Protocol.....	3
1. Introduction	3
2. Settings and Connection	3
3. Commands	3
3.1. Information Commands	3
3.2. Parameter Setting and Control Commands:.....	7
4. Unsolicited or Broadcast Messages	9
5. VR Memory Locations	12

HRPD Sample Changer Serial Protocol

1. Introduction

This unit has serial communication incorporated to allow and provide status and control.

There are several commands that are intended for computer group but can be used from a dumb terminal, e.g. hyper-terminal or putty.

There are several commands that are intended for dumb terminal only.

All commands are described in section 3

There are some unsolicited or broadcast message intended for dumb terminal that can be enabled as detailed in section 0

2. Settings and Connection

The unit is configured to run RS232c at 38400 baud, 8N1.

The terminating character is ascii 10 (CR)

Connection is made to the female 9-way D-type connector on the front of the cabinet.

The port is configured as DCE (Data Communications Equipment).

3. Commands

The command set has been designed to be as compatible with GEM and POLARIS as reasonably possible. Some changes had to be made to reflect the new hardware and abilities, also some additional commands have been provided. All lines need a carriage return character to be sent.

Purging the current line can be done by putting an exclamation mark “!” at the end of the line before the carriage return.

The serial input is buffered and only processed when the carriage return is received. If the buffer size exceeds 29 characters or there is an excessive gap in the serial stream then the buffer contents will be discarded an information message produced.

Any line that is not recognised will be ignored responded with two question marks.

3.1.Information Commands

Shown in alphabetical order

The input command is shown bold with the response field descriptions, followed by a typical system response.

db	Debug Inputs	
In(0)	= Motor 1 Up/Down	= Disabled
In(1)	= Motor 0 Rotate	= Disabled
In(2)	= Interface Loop	= On
In(3)	= Unused	= Off
In(4)	= Unused	= Off
In(5)	= Insertion Arm UP	= Yes
In(6)	= Drive 0 Rotate Fail	= NO
In(7)	= At Index Position	= Yes
In(8)	= At Position 1	= No

HRPD Sample Changer – Serial Protocol

In(9) = Sample Rod Up = Yes
 In(10) = Sample Rod Down = No
 In(11) = Step 1 Up/Down = Low
 In(12) = Direction 1 Up/Down = Raise
 In(13) = Drive 1 Up/Down Fail = No
 In(14) = Step 0 Rotate = Low
 In(15) = Direction 0 Rotate = Forward
 Op(8) = Cardcheck = High
 Op(10) = Drv 1 Up/Down Reset = Low
 Op(13) = Drv 0 Rotate Reset = Low
 Op(14) = Motor 0 Rotate = Disabled
 Op(15) = Motor 1 Up/Down = Disabled
 Insertion Arm Motor = Stopped
 Rotary Indexer Motor = Stopped
 Last Error Number was = 0
 Rotating Carousel Position = 17

hp Help – show commands

Valid commands are:-

db(rtn) to debug inputs

hp(rtn) show commands

id(rtn) to give PnP identity

st(rtn) to give status

po(rtn) to give position in(rtn) to initialise carousel

ma[nn](rtn) move to position [nn] and lower

mn[nn](rtn) move to position [nn] but not lower

ra(rtn) to raise arm.

lo(rtn) to lower arm

fw(rtn) move up 1 position

bk(rtn) move down 1 position

sa(rtn) show sample status

rt(rtn) retrieve dropped sample

ht(rtn) halt all movement, in required

r0(rtn) reset drive 0

r1(rtn) reset drive 1

vr[nnnn] show memory vr contents

Error 1 = Can't find 'any index' sensor

Error 2 = Can't find index position 1 after 20 tries

Error 3 = Can't lower arm if not at index

Error 4 = Insertion arm Retract FAILED

Error 5 = Invalid Destination

Error 6 = Rotary index not Initialised

Error 7 = Sample arm has dropped

Error 8 = Sample arm is not down

Error 9 = Busy or unsafe

Error 10 = Cannot Rotate when Actuator not up

Error 11 = Can't Rotate if not up

Error 12 = Halt executed

Error 13 = No SD Card

HRPD Sample Changer – Serial Protocol

Error 20 = Drive 0 Rotate fail
 Error 21 = Drive 1 Up/Down fail
 Error 22 = No interface card
 Error 24 = Too fast or dropped sample
 Error 25 = Too fast
 Error 30 = Process Stopped ---Monitor
 Error 31 = Process Stopped ---Polaris1
 Error 32 = Process Stopped ---Logging
 Error 33 = Process Stopped ---Motors
 Error 34 = Process Stopped ---Moveabs
 Error 40 = Monitor Basic Error
 Error 41 = Polaris1 Basic Error
 Error 42 = Logging Basic Error
 Error 43 = Motors Basic Error
 Error 44 = Moveabs Basic Error

id Unit Identity
 0001 0001 ISIS HRPD Sample Changer V1.00

po Carrousel Positon, 1-20 or -1 for unknown.
 Position = 20

sa Sample Status 1 to 20
 UUUUUU?UUUU?U?UUxxU
 Where
 x = not tested
 ? = dropped
 U = up
 D = down
 ! = up and down
 # = bad combination of bits

st Status of system
 1110011111001100 00 01

The first 16 characters are the 16 inputs used by the controller these are:

0 Motor 1 (Up/Down)	0 = Enabled	1 = Disabled
1 Motor 0 (Rotate)	0 = Enabled	1 = Disabled
2 Interface Card Check	0 or 1 No significance	
3 Unused		
4 Unused		
5 Actuator Arm Position	0 = Not Up	1 = Up
6 Drive 0 (Rotate) Status	0 = Working	1 = Error
7 Carrousel at Index	0 = Off Index	1 = At Index
8 Carrousel at Position 1	0 = Off 1	1 = At Position 1
9 Sample Arm Up	0 = Not Up	1 = Up
10 Sample Arm Down	0 = Not Down	1 = Down
11 Step 1 (Up/Down)	toggles during movement	

HRPD Sample Changer – Serial Protocol

12 Direction 1 (up/Down)	0 = Lower	1 = Raise
13 Drive 1 (Up/Down)	0 = Working	1 = Error
14 Step 0 (Rotate)	toggles during movement	
15 Direction 0 (Rotate)	0 = Forward	1 = Backward
The next 2 shows motor activity		
Motor 1 (Up/Down)	0 = Idle	1 = Active
Motor 0 (Rotate)	0 = Idle	1 = Active

The Next 2 shows error

- 0 = No error
- 1 = Can't find 'any index' sensor
- 2 = Can't find index position 1 after 20 tries
- 3 = Can't lower arm if not at index
- 4 = Insertion arm Retract FAILED
- 5 = Invalid Destination
- 6 = Rotary index not Initialised
- 7 = Sample arm has dropped
- 8 = Sample arm is not down
- 9 = Busy or unsafe
- 10 = Cannot Rotate when Actuator not up
- 11 = Can't Rotate if not up
- 12 = Halt executed
- 13 = No SD Card
- 20 = Drive 0 Rotate fail
- 21 = Drive 1 Up/Down fail
- 22 = No interface card
- 24 = Too fast or dropped sample
- 25 = Too fast
- 30 = Process Stopped ---Monitor
- 31 = Process Stopped ---Polaris1
- 32 = Process Stopped ---Logging
- 33 = Process Stopped ---Motors
- 34 = Process Stopped ---Moveabs
- 40 = Monitor Basic Error
- 41 = Polaris1 Basic Error
- 42 = Logging Basic Error
- 43 = Motors Basic Error
- 44 = Moveabs Basic Error

The final 1 is carousel position 1-20 or -1 for unknown

vr0011 Read any Variable, in this case 0011 which is carrousel position. The content is shown in decimal and hexadecimal formats as well as its polarity. A selection are shown in 0 on page 9. Further locations can be provided on request.

+ VR 11 = 17 hx 11

3.2.Parameter Setting and Control Commands:

The following commands can be keyed in and a description is given of the full sequence that should follow. These are shown in alphabetical order. The unit will respond with either “ok” if accepted or “rj-xx” if reject, xx is numerical for cause identification purposes.

bk	Backward Carousel This function will cause the rotary carousel to move one position anticlockwise as viewed from the top.
fw	Forward Carousel This function will cause the rotary carousel to move one position clockwise as viewed from the top.
ht	Halt This will immediately halt all movements, positional integrity will be lost, sample information will be initialised, operation after this command cannot be guaranteed. The “in” command will be needed to continue. This command should only be used if there is a severe problem, it should not be used to clear a command being executed.
r0	Reset Drive 0, rotate This will reset drive 0; any pending move operations will be effected. This should only be used if the drive is showing an error.
r1	Reset Drive 1, Up/down This will reset drive 1; any pending move operations will be effected. This should only be used if the drive is showing an error.
in	Initialisation This function causes the actuator arm to rise, if required, and then the carousel will be rotated until position 1 is found.
lo	Lower sample arm This function causes the actuator arm to go downwards. This will push the selected sample arm down, and place the sample in the beam.
ma07	Move to Absolute Position, sample 7 in this case. This function will cause the full sequence of events needed to select a new sample. It will raise the existing sample from the beam, if required, move via the quickest route to the new required sample and lower that sample into the beam.
mn06	Move Without Lowering to Absolute Position, sample 6 in this case. This is similar to ma above but it will not lower the selected sample into the beam.

ra Raise Sample Arm
This function causes the actuator arm to lift. This will draw the selected sample arm upwards until it is parked in a detent, at which point the magnetic coupling will be forced to break as the actuator arm rises a little further.

rt Retrieve Dropped Sample Arm
This Function causes the actuator arm to go downwards beyond the beam position and to the bottom of the tube. The “ra” or “lo” commands can then be used to raise the sample from this position to either the top or the beam position respectively.

DRAFT

4. Unsolicited or Broadcast Messages

These are produced to show system status and progress, they are essential to check system operation and in any fault diagnosis. They show operational information, input and status changes. As they occur they are stored for writing to the sd card on the Euro 404 controller card every few seconds. If selected they will also appear on the serial port.

The memory will only hold 40 records prior to sd card writing, if any more are generated within the writing cycle they will be counted but lost, This count will be included in the information stored on the sd card. When the information is written to the sd card it will also appear on the serial port if selected.

The system will operate without an sd card or broadcast enabled and captured, however activity will not be logged and therefore any unexpected behaviour cannot be debugged, supported or any faults diagnosed.

”.

Control from the Unit.

These can be switched on or off from the Communications Screen. They can be switched off only from the User screen.

Control from the serial port

bn Broadcast Mode On
INF 32 Broadcast ON

bf Broadcast Mode Off
INF 33 Broadcast Off

The messages are:

INF 01 Event Overflow --- The number show is a count of the events that were not logged as the memory is full, the memory capacity is 40.

INF 02 Drive 0 reset --- The reset signal on drive 0 (rotate) is active by HMI button

INF 03 Drive 0 release --- The reset signal on drive 0 (rotate) is released by HMI button

INF 04 Drive 1 reset --- The reset signal on drive 1 (up/down) is active by HMI button

INF 05 Drive 1 release --- The reset signal on drive 1 (up/down) is released by HMI button

INF 06 Clock Change..... --- the clock has changed

INF 07 Bad Clock Change.... --- the clock change request was rejected due to a stated value being out of range.

INF 08 Serial Drive 0 reset 500 mS --- The reset signal on drive 0 (rotate) is active for 500mS by serial command.

INF 09 Serial Drive 0 release --- The reset signal on drive 0 (rotate) has been released after timeout

INF 10 Serial Drive 1 reset 500 mS --- The reset signal on drive 1 (up/down) is active for 500mS by serial command

INF 11 Serial Drive 1 release --- The reset signal on drive 1 (up/down) has been released after timeout

INF 13 Manual Forward --- is being performed

INF 14 Manual Backward --- is being performed

HRPD Sample Changer – Serial Protocol

INF 15 Manual Raise --- is being performed
INF 16 Manual Lower --- is being performed
INF 17 Manual Retrieve --- is being performed

INF 19 Manual init--- is being performed
INF 20 Auto Init--- is being performed
INF 21 Auto Move Absolute....--- is being performed
INF 22 Auto Move Absolute No Lower.....--- is being performed
INF 23 Auto Forward--- is being performed
INF 24 Auto Backward--- is being performed
INF 25 Auto Raise --- is being performed
INF 26 Auto Lower..... --- is being performed
INF 27 Auto Retrieve..... --- is being performed

INF 29 At Position.. was... ---carousel has moved
INF 30 At Position.. was... ---carousel has moved
INF 31 config..... --- configuration information at start up
INF 32 Broadcast on --- broadcast mode has been switched on
INF 33 Broadcast off ---broadcast mode has been switched off

INF 35 Manual Mode --- the unit has been but into manual mode
INF 36 Auto Mode --- the unit has been put into automatic mode
INF 37 ID check --- the units identification has be queried serially

INF 38 Serial String too long --- the received serial string is already too long and will be discarded.
INF 39 Serial Time-out --- an excessive gap was detected in the serial command, it has been discarded.

INF 43 Misc --- miscellaneous information from the monitor process
INF 44 Misc --- miscellaneous information from the polaris1 process
INF 45 Misc --- miscellaneous information from the logging process
INF 46 Misc --- miscellaneous information from the motor process
INF 47 Misc --- miscellaneous information from the moveabs process

INF 50 Error .. cleared by monitor --- an error has been cleared
INF 51 Error .. cleared by Polaris1 --- an error has been cleared
INF 52 Error .. cleared by Logging --- an error has been cleared
INF 53 Error .. cleared by Motor --- an error has been cleared
INF 54 Error .. cleared by Moveabs --- an error has been cleared

INF 60 Monitor Started on: ... --- process started
INF 61 Polaris1 Started on: ... --- process started
INF 62 Logging Started on: ... --- process started
INF 63 Motor Started on: ... --- process started
INF 64 MoveABS Started on: ... --- process started
INF 65 Logging Restarted on: ... --- process started

HRPD Sample Changer – Serial Protocol

INF 70 1-Process Stopped Monitor
INF 71 1-Process Stopped Polaris1
INF 72 1-Process Stopped Logging
INF 73 1-Process Stopped Motor
INF 74 1-Process Stopped Moveabs

INF 80 1-Process Restarted Monitor
INF 81 1-Process Restarted Polaris1
INF 82 1-Process Restarted Logging
INF 83 1-Process Restarted Motor
INF 84 1-Process Restarted Moveabs

BER 10 Monitor Basic Error --- a basic error was encountered and a system reset is required

BER 11 Polaris1 Basic Error --- a basic error was encountered and a system reset is required

BER 12 Logging Basic Error --- a basic error was encountered and a system reset is required

Some basic errors relating to sd card will self reset the process

BER 13 Motor Basic Error --- a basic error was encountered and a system reset is required

BER 14 Moveabs Basic Error --- a basic error was encountered and a system reset is required

INP 199 PREV 8391 UP 0 DOWN 8192 ,D1F

changes to the inputs selected in section 3 on page 5 will be logged as shown with mnemonics, subject to line space.

The mnemonics are:

- IFL --- Interface card loop test
- D1F --- Drive 1 (up/down) failure
- D0F --- Drive 0 (rotate) failure
- SAD --- Sample Arm Down
- SAP --- Sample Arm Up
- ATH --- Carousel at home position 1
- IDX --- Carousel at an Index position
- AAU --- Actuator Arm Up
- DR0 --- Direction 0 (rotate)
- ST0 --- Step 0 (rotate)
- M0E --- Motor 0 (rotate) enable
- DR1 --- Direction 1 (up/down)
- ST1 --- Step 1 (up/down)
- M1E --- Motor 1 (up/down) enable
- IN4 --- Input 4 not used
- IN3 --- Input 3 not used

ERR any error message as described in the Error section of the user manual will produce a logged message.

5. VR Memory Locations

A selection of memory locations:

0033	HMI page number
0040	Axis 0 (rotate) speed
0042	Axis 0 (rotate) step position /100
0043	Lower depth target thousands
0044	Lower depth target units
0045	Retrieve depth target thousands
0046	Retrieve depth target units
0050	Axis 1 (up/down) speed
0052	Axis 0 (up/down) -step position /100
0061	RTC Hour
0062	RTC Minutes
0063	RTC Seconds
0064	RTC Day
0065	RTC Month
0066	RTC Year
0110	Logging file number
0350	Logging write count 0 to 40
0352	Logging overflow count
0363	Input Logging Mask