Gemini2 Series Firmware Upgrade

 $1_{\text{\tiny N}}\,$ First, use OrbbecViewer to connect the device as shown in the following image $_{\text{\tiny o}}$

Crbbec	Viewer									\Box \times
	Orbbec Gemini 2 L SN#AY8T43E000C USB	3.0 ~		Color	Depth	IR	IMU	PointCloud		
	Device Control									
-	■ Color >				More			~		
0	■ Depth >				WOIE					
Camera	■ IR >			Online firmware up	grade:					
	■ IMU >			No new firmware ca	in be updated					
	Data Management >									
Ť										
Advanced		Dev	viceInfo							
		C C								
		F								
		s								
				Firmware: Input or	select one firmv	vare file	•			
					Ilemente					
					Opgrade			L.		i v
		# Eirr	mware							
		# 501	IIIwaie					1000		
		ŧ.						valid: 0		
		* #								
		#								
<u> </u>		‡ +				Historical Firm	vare Versions	main	• • ••••••••••••••••••••••••••••••••••	鲍什由兴
中/英		#93 [3	INFO] Sta	ge Version: ma	in					ORBBEC

2 S After selecting the firmware , enter the existing updated firmware image file in the "Firmware" input box, and click the "Upgrade" button to start the update.



3、 The successful upgrade interface is shown below:



4、 reboot the device and verify the firmware version

First, click Reboot button, reboot the device, then verify the firmware version info.

More									
	PID: 0x0673 FW Version: 1.4.42 Chip Type: MX6600 SDK Version: 1.9.2		VID: 0x2BC5 SN: AY8T43E000C Connection: USB3.0 Log Severity: DEFAULT						
DeviceInfo	Temperature: Refresh Laser: 28.9 °C RGB: 27.9 °C IRLeft: 27.7 °C IRRight: 27.8 °C IMU: 0.0 °C ExtensionInfo:	WatchDog: Heartbeat: Device: Re	o ooot						
Firmware									