



## Test Plan Execution Report

Test Project: Desktop  
Test Plan: Server smoke test  
Test Suite: Smoke test

Printed by TestLink on 10/16/2019

2012 © TestLink Community

## Test Suite : Smoke test

---

Test Case desktop-111: Server smoke test via desktop client [Version : 1]				
#:	Step actions:	Expected Results:	Execution notes:	Execution Status:
1	Connect with username and password	User has been logged in		Passed
2	Connect with LDAP and oAuth	User has been logged in	Tested with community tarball	Passed
3	Connect with LDAP and Shibboleth (client 2.5)  https://marketplace.owncloud.com/apps/user_shibboleth  docker-compose -f owncloud-base.yml -f owncloud-official-mount-core.yml -f owncloud-exported-ports.yml -f idp/simplesaml.yml -f idp/simplesaml-auth-basic.yml -f idp/simplesaml-apache-basic.yml up	User has been logged in	Waiting for new docker image with new Ubuntu	Blocked
4	Sync a file from a server to a client	File has been synced to the client		Passed
5	Share a file via public link (create a new public link via Sharing dialog that can be opened from the context menu)	Public link has been created and is accessible		Passed
6	Create a new file	The file has been synced to the server		Passed
7	Share the file via User and Group share	The new collaborator has received the share		Passed
8	Make changes to the content of the shared file	Changes have been synced to the server  Collaborator has received the changes	Not available	Blocked
9	Rename a file	Changes have been synced to the server  Collaborator has NOT received the changes		Passed
10	Move a file	Changes have been synced to the server		Passed

		Collaborator has NOT received the changes		
11	Delete the file	File has been deleted on the server File has been deleted also from the collaborator		Passed
12	1. Go to Activity tab 2. Check the server activity	Server activities have been logged	Not available	Blocked
<u>Execution type:</u>	Manual			
<u>Estimated exec. duration (min):</u>				
<u>Priority:</u>	Medium			
<b>Execution Details</b>				
Build	10.3.0			
Tester	hgemela			
<u>Execution Result:</u>	<b>Passed</b>			
<u>Execution Mode:</u>	<b>Manual</b>			
<u>Execution duration (min):</u>				